



1 Place wire in connector



2 Fold connector over wire with pliers



3 Squeeze connector until it locks



4 Insert wire into spade, crimp down to secure wire



5 Plug the spade terminal into tap connector directly



6 Secure and insulated connection done